

## Sony P2 Device Numbers

When a Controlled device responds correctly to the Device Type Request command (00.11) with the device type code the controlling device can setup the name and parameters correctly. There are 4,096 codes available, not all have been used although some have been used more than once.

One of the main features of the SR/MR remote controls/Synchronizers is the ability to auto-configure to suit the connected device. The device type code provides this information.

This list includes all of the devices that we know, we try to keep it up to date. If you would like your product to be included in this list, or you find a device not in this list please E-Mail the product name and device type to us and we will include it for future reference. Our intention is to keep this list up to date, we can only do this with your help.

The parameter 'x' represents the timecode standard of the machine as follows:

|   |       |                            |
|---|-------|----------------------------|
| 0 | SMPTE | 29,97/30 frames per second |
| 1 | EBU   | 25 frames per second       |
| 2 | Film  | 24 frames per second       |

CB Electronics also support a three byte ID where the third byte is defined as follows:

Bits 0..3 = Machine Number, allows multiple machines of the same type to be identified when connected to the system

Bits 4..7 = Number of tracks / 8

Example:

Fx B2 21 = Pyramix 16 Tracks, Machine 1 (Displayed as PMX-16a)

Fx B2 62 = Pyramix 16 Tracks, Machine 1 (Displayed as PMX-48b)

|       |                   |             |                   |       |                 |
|-------|-------------------|-------------|-------------------|-------|-----------------|
| 0x.00 | BVH-1100          | 0x.91       | CB AK ES1         | 1x.28 | SVP-9020        |
| 0x.01 | BVH-2000          | 0x.92       | CB VS-1           | 1x.2C | SVO-9620        |
| 0x.10 | BVH-2000          | 0x.93       | CB Timeline Lynx  | 1x.34 | DAR-OMR8        |
| 0x.11 | BVH-2000          | 0x.94       | CB MRP-16         | 1x.48 | VO-9800         |
| 0x.14 | BVH-2000P         | 0x.95       | CB Ampex DCT700   | 1x.4C | VO-9850         |
| 0x.15 | BVH-2000P         | 0x.96       | CB Ampex VPR-3    | 1x.80 | BVU-900         |
| 0x.18 | BVH-2180          | 0x.97       | CB Ampex VPR-6    | 1x.E0 | Nagra-T         |
| 0x.19 | BVH-2180          | 0x.98       | CB Ampex XVR-80   | 1x.E1 | Nagra-D         |
| 0x.1C | BVH-2180P/Stud V8 | 0x.99       | CB Ampex VPR-300  | 1x.F0 | VO-5850         |
| 0x.1D | BVH-2180P         | 0x.9A       | CB Ampex VPR-80   | 1x.FF | DMR-2000        |
| 0x.20 | BVH-2500          | 0x.A0       | CB P2MMC          |       |                 |
|       | DVS-6/7/800C      | 0x.A1       | CB TG-2           |       |                 |
|       | /HDDF-500         | 0x.A2       | CB PioneerDVD I/F | 2x.00 | BVW-10          |
| 0x.24 | BVH-2500P         | 0x.A3       | CB P2DVD          | 2x.01 | BVW-40          |
| 0x.30 | BVH-2700          | 0x.A4       | CB P2MMC-USB      | 2x.02 | BVW-11          |
| 0x.40 | BVH-2800          | 0xA5        | CB Quicktime      | 2x.03 | BVW-15          |
| 0x.44 | BVH-2800P         | 0x.B0       | CB SR-GEN         | 2x.10 | BVW-35          |
|       | DME-3/5/7000      | 0x.B1       | CB SR-RDR         | 2x.18 | BVW-35P         |
| 0x.48 | BVH-2830          | 0x.E0       | HDD-1000          | 2x.20 | BVW-60          |
| 0x.4C | BVH-2800P         | 0x.F0       | HDV-1000          | 2x.21 | BVW-65          |
| 0x.50 | BVH-3000          | 0xFF        | DMR-2000          | 2x.22 | BVW-95          |
| 0x.52 | BVH-3000P         |             |                   | 2x.23 | BVW-96          |
| 0x.54 | BVH-3000P         | 1x.00       | BVU-800           | 2x.24 | BVW-70          |
| 0x.60 | BVH-3100          | 1x.01       | BVU-820           | 2x.25 | BVW-75 (GV-K2)  |
| 0x.62 | BVH-3100P         | 1x.02       | BVU-850           | 2x.26 | BVW-85P         |
| 0x.64 | BVH-3100P         | 1x.03       | BVU-870           | 2x.29 | BVW-65P         |
| 0x.70 | CB Studer D820    | 1x.12       | DAR OMR-8         | 2x.2A | BVW-95P         |
| 0x.71 | CB Studer TLS-1   | 12.12.2x.41 | Datavideo DN-300  | 2x.2C | BVW-70S         |
| 0x.72 | CB Studer A807    | 1x.18       | BVU-900           | 2x.2D | BVW-75P         |
| 0x.73 | CB Studer A812    | 1x.19       | BVU-920           | 2x.2F | WBR-700         |
| 0x.74 | CB Studer A820T   | 1x.1C       | BVU-950           | 2x.30 | BVW-50 (CVR-50) |
| 0x.75 | CB Studer A820M   |             | Radar-1           | 2x.40 | PVW-2600        |
| 0x.81 | CB Studer A820-24 | 1x.20       | SVO-5800          | 2x.41 | PVW-2800        |
| 0x.90 | CB Dubber         | 1x.21       | SVP-5600          | 2x.42 | PVW-2650        |

|       |                |         |                    |       |                   |
|-------|----------------|---------|--------------------|-------|-------------------|
| 2x.45 | BVW-D265       | 8x.15   | DSR-1800           | Dx.17 | Aysis Air         |
| 2x.46 | BVW-D75        |         |                    | Dx.18 | Avant             |
| 2x.47 | BVW-9000       | 9x.00   | DEM-1000           | Dx.19 | Axiom MT          |
| 2x.50 | UVW-1600       | 9x.10   | HDDF-500           | Dx.30 | MAV-1000          |
| 2x.51 | UVW-1800       | Ax.00   | ASC-VR             | Dx.31 | MAV-1200          |
| 2x.52 | UVW-1700G      | Ax.01   | LVR-5/6000AP       | Dx.40 | DME-9000          |
| 2x.A0 | SRW-5000       | Ax.02   | LVR-3/4000         | Dx.50 | DADR-5000         |
| 2x.A1 | SRW-5500       | Ax.07   | M2 AU-750          | Dx.50 | ADSG 16           |
| 2x.A2 | SRW-5800       | Ax.10   | LVA-7/8000         | D8.50 | FF Digideck       |
| 2x.E0 | HDW-500        | Ax.11   | LVA-3/4000         | Dx.51 | DADR-5032         |
| 2x.E2 | HDW-2000/M200P | Ax.20   | CDP-3100           | Dx.52 | DADR-5048         |
| 2x E3 | HDW-2000       | Ax.30   | PCM-9000           | Dx.53 | DADR-5064         |
| 2x E4 | HD CAM J-H3    | Ax.40   | BKDE-550 (TRUDI)   | Dx.70 | QuBit ST          |
| 2x.F0 | HDV-10         | Ax.4D   | Gallery VirtualVTR | Dx.71 | QuBit EL/DS       |
| 2x.F9 | HDV-500        | Ax.50   | Doremi V1          | Dx.81 | DPS-PVR           |
|       |                | Ax.80   | SVHS AG-7750       | Dx.90 | DN-C680           |
| 3x.00 | DVR-1000       | Ax.81   | SVHS AG-7650       | Dx.91 | DN-M51050R        |
| 3x.03 | Augan-OMX-24   | Ax.82   | DS-850             | Dx.A0 | P2MMC-MX2424      |
| 3X.10 | DVR-2000       | Ax.86   | AG-8700            | Dx.A1 | AVID Media Comp   |
| 3x.11 | DVR-2100       | Ax.88   | DS555 SVHS         | Dx.A2 | AVID A/S 16       |
| 3x.E0 | Bonsai         | Ax.91   | XDCAM Blue Ray     | Dx.A3 | AVID A/S 32       |
|       |                | Ax.A1   | Soundmaster Atom   | Dx.A8 | AVID A/V 24       |
| 4x.00 | DVR-10         | Ax.C0   | JoeCo BBR          | Dx.A9 | AVID A/V 8        |
| 4x.02 | DVR-C10        | Ax.C1   | JoeCo. BBR64       | Dx.AA | AVID A/V 16       |
| 4x.03 | DVR-18         | Ax.F0   | HDL-5800           | Dx.AB | AVID A/V 32       |
| 4x.10 | DVR-2          |         |                    | Dx.E1 | Protocols 24T     |
| 4x.20 | DVR-20         | Bx.00   | DVW-A500           | Dx.B0 | Otari RADAR       |
| 4x.21 | DVR-C10        | Bx.01   | DVW-A510           | Dx.C0 | Genex GX2000      |
| 4x.22 | DVR-28         | Bx.02   | DVW-CA500          | Dx.C1 | Genex GX8000      |
| 4x.23 | DVR-P20        | Bx.03   | DVW-CA510          | Dx.C2 | Genex GX8016      |
|       |                | Bx.10   | DVW-500            |       | OMX 24            |
| 5x.00 | APR-5003V      |         | DSr-85             | Dx.C3 | Genex GX8024      |
| 5X.24 | APR-24         | Bx.11   | DVW-510            | Dx.C4 | Genex GX8032      |
| 5x.33 | AJD-750        |         | DSR-80             | Dx.C5 | Genex GX8040      |
|       |                | Bx.12   | DVW-C500           | Dx.C6 | Genex GX8048      |
| 6x.02 | PCM-3402       |         | DSR-60             |       | Genex GX8050      |
| 6X.03 | PCM-3324S      | Bx.13   | DVW-C510           | Dx.C7 | Genex GX8056      |
| 6X.05 | PCM-3348 HRV   | Bx.30   | DVW-250            | Dx.C8 | Genex GX8064      |
| 6X.07 | PCM-3348 HR    | Bx.40   | DNW-A100           | Dx.D0 | Dolby Drive       |
|       |                | Bx.41   | DNW-A100           | Dx.D1 | Dolby Drive       |
| 7X.00 | PCM-7030       | Bx.45   | DNW-A45/50         | Dx.D4 | dAVE SP           |
| 7X.01 | PCM-7050       |         | DNW-A46            | Dx.E1 | Protocols         |
| 7X.02 | PCM-7010       | Bx.46   | DNW-A75            | Dx.F3 | Zeta 3            |
| 7X.03 | PCM-800        | Bx.48   | DNW-A30            | Dx.F8 | CB MC-1           |
| 7X.04 | PCM-7040       | Bx.49   | DNW-30             | Dx.F9 | LANC I/F          |
| 7x.A2 | Alesis A1-2    | Bx.4A   | DNW-220            | Dx FA | TimeMachine C-Lab |
| 7x.E0 | M20            | Bx.4C   | DNW-220            | Dx FB | SyncStation       |
| 7x.E1 | M20-16         | Bx.60   | MSW-M2000          |       |                   |
| 7x.E2 | M20-24         | Bx.70   | Sony J-3           | Ex10  | RaveHD Spectsoft  |
| 7x.E3 | M20-32         |         |                    | Ex 20 | XDubber           |
| 7x.E4 | M20-40         | Dx.00   | DME-5000           | Ex 30 | OpenCube          |
| 7x.E5 | M20-48         | Dx.01   | V-MOD 100          | Fx.00 | JVC CR-850        |
| 7x.E6 | M20-56         |         | DME-9000           |       | Bosch BCN-50      |
| 7x.E7 | M20-64         | Dx.02   | DME-3000           | FE.01 | Drastic VVTR      |
|       |                | Dx.10   | Screenound         | Fs.01 | Prunus            |
| 8X.01 | Yamaha DRU-8   | D8/9.10 | EVS Odetics        | Fx.02 | Bosch BCN-52      |
| 8x.08 | EVO-9800       | Dx.11   | SL 9000j           | Fx.03 | Abekas A62/A66    |
| 8x.0C | EVO-9850       | Dx.12   | Axiom              |       | Ampex VPR-3       |
| 8x.10 | DSR-85         | Dx.13   | APS                |       | Diskus            |
| 8x.11 | DSR-80         | Dx.14   | DMC/Scenaria       | Fx.04 | Abekas A64        |
| 8x.12 | DSR-60         | Dx.15   | Omnimix            |       | Ampex VPR-3       |
| 8x.14 | DSR-2000       | Dx.16   | VisionTrack        | Fx.05 | Abekas A60        |

|          |                   |         |                                    |
|----------|-------------------|---------|------------------------------------|
|          | Ampex VPR-3       | F8/9.4d | EVS DD35                           |
| Fx.06    | Ampex VPR-3       | Fx.51   | Pioneer PRV-LX10<br>(DVD Recorder) |
|          | Abekas A53D       |         |                                    |
| Fx.07    | Ampex VPR-6       | Fx.88   | Sondor                             |
| Fx.08    | Abekas A53D/A57   | Fx.90   | CTM Kolibri                        |
| Fx.09    | Bosch DCR100      | Fx.A0   | F'Light MFX3                       |
| Fx.0A    | JVC KR-M800       | Fx.A1   | F'Light Vivid                      |
|          |                   | Fx.A2   | F'Light MFX-3A                     |
| Fx.0B    | JVC SA-F911       | Fx.A3   | F'Light V-Motion                   |
|          | BRS-662           | Fx.B0   | Merging VCube                      |
| Fx.0C    | Hit VL-D500       | Fx.B1   | Merging Luxor 96                   |
| Fx.0D    | Hit VL-D505       | Fx.B2   | Merging Pyramix                    |
| Fx.0E    | Hit VL-S100       | Fx.B3   | Merging V.T.                       |
| Fx.0F    | Fostex G-24       | Fx.B4   | Merging VCube                      |
|          | Fostex DVD-40     |         |                                    |
| Fx.10    | Fostex D-20       | Fx C0   | Chinkel Cappella                   |
| Fx.10.30 | Fostex D-30       |         |                                    |
| Fx.10.10 | Fostex D-10       | Fx.D1   | StarSync                           |
| Fx.10.20 | Fostex D-20       |         |                                    |
| Fx.11    | Abekas A84        | Fx.DE   | SoundscapeSync Card                |
| Fx.12    | Abekas A82        | Fx.DF   | Synchronos Rythmo                  |
| Fx.13    | VPR 2/300         | FxE0    | Mosaic Video Rythmo                |
| Fx.14    | VPR-305           |         | BlackMagic                         |
| Fx.15    | VDR-V100          | FxE2    | Echo Video                         |
| Fx.16    | VDR-V100          |         |                                    |
| Fx.17    | VDR-V100          |         |                                    |
| Fx.18    | VDR-V100          |         |                                    |
| Fx.19    | AJ-D350           |         |                                    |
| Fx.1A    | MMR-8,MRP-16      |         |                                    |
|          | MX2424            |         |                                    |
| Fx.1B    | Tascam DA-60      |         |                                    |
| Fx.1C    | Tascam DA-30      |         |                                    |
| Fx.1D    | Tascam DA-88      |         |                                    |
| Fx.1E    | Hit HD-1200       |         |                                    |
| Fx.1F    | JVC BR-S822E      |         |                                    |
| Fx.20    | Quickframe        |         |                                    |
| Fx.21    | RTD-4224          |         |                                    |
| Fx.22    | RCI 5/625         |         |                                    |
| Fx.23    | RCI HD rt         |         |                                    |
| Fx.24    | RCI HD nonrt      |         |                                    |
| Fx.25    | DCT               |         |                                    |
| Fx.26    | JVC BR-S800E      |         |                                    |
|          | DCT700            |         |                                    |
| Fx.27    | Otari DTR-90      |         |                                    |
| Fx.28    | Otari DTR-90      |         |                                    |
| Fx.29    | MotionWorker      |         |                                    |
| Fx.2A    | Studer D424       |         |                                    |
| Fx.31    | Pioneer 9601      |         |                                    |
| Fx.32    | JVC BR-S85E       |         |                                    |
| Fx.33    | AG DVCPRO         |         |                                    |
|          | AJD750            |         |                                    |
| Fx.34    | Akai DR8          |         |                                    |
| Fx.35    | Akai DR16         |         |                                    |
| Fx.36    | Akai DD1500       |         |                                    |
| Fx.37    | DVS Prontoserver  |         |                                    |
| Fx.39    | Akai DD8          |         |                                    |
| Fx.3C    | ES/2              |         |                                    |
| Fx.3A    | JVC BR-D92E       | DIGI-   |                                    |
|          | SVHS              |         |                                    |
| Fx.3D    | AMS Encore        |         |                                    |
| Fx.43    | 360 Systems TCR-4 |         |                                    |
| Fx.44    | 360 Systems TCR-8 |         |                                    |